

## TOOLS YOU MAY NEED

- Sturdy step stool or step ladder
- Clean sponge
- Razor blade knife and extra blades
- Clean water and a water tray
- Drop cloth
- Wallpaper smoothing brush

## HANGING PROCEDURE

The wall surface must be clean and dry. The application of "wallpaper primer" is **recommended for surfaces painted with latex**. High Gloss and Semi-Gloss paint surfaces **need to be sanded**.

To apply on **clean, painted walls, soak the prepasted border for 45 seconds in lukewarm water** ~ fold the strip paste side to paste side in two foot sections. When applying to the wall, **unfold each section as you go**, gently smoothing into place. Wash with a sponge to remove excess paste.

If applying **over wallcoverings**, do not wet ~ use a water-based vinyl-to-vinyl adhesive.

## CARE & CLEANING

Once installed, your wallcovering may be cleaned using a soft sponge and a lukewarm, mild detergent solution. Do not use abrasive cleaners containing chlorine bleach, solvents, or ammonia as they may attack and damage the printed surface.

## WARRANTY

Shop4wallpaper warrants its finished product to be free of defects in material and workmanship for a period of 90 days from purchase, and will replace any material found to be defective. Please inspect all goods immediately upon receipt. Shop4wallpaper is not responsible for labor charges, improper installation, installation of incorrect goods (those not approved or confirmed by the customer), removal of goods, or problems arising from defects in the construction, surface, or preparation of the wall.