

**THANK YOU FOR PURCHASING OUR QUALITY PRE-PASTED MURAL.
BEFORE YOU BEGIN, PLEASE:**

- **OPEN** and thoroughly inspect the product for defects.
- **CONFIRM** that this is the correct product.
- **VERIFY** all wall and product dimensions.
- **CHECK** the alignment of the pattern across panels prior to hanging.
- **ASSESS** walls for bowing, sagging or uneven surfaces as these may cause misalignment.
- **STOP** immediately and contact 4walls if any discrepancy is discovered.

- We strongly recommend laying out all mural panels prior to installation. This will help determine the best starting point and help detect any problems that may arise during installation.
- All seams include a small amount of overlap. Please take care when matching the pattern at a seam to accommodate this feature.

TOOLS YOU MAY NEED

- Sturdy step stool or step ladder
- Clean sponge
- Razor blade knife and extra blades
- Clean water and a water tray
- Tape measure
- Drop cloth
- Level or plumb bob
- Straight edge
- Seam roller

WALL PREPARATION

Murals may be applied to any dry, clean, smooth surface. Old wallpaper or other surface materials should be removed before application.

Fill cracks with a spackling compound or plaster patching and sand to a smooth surface. Glossy or enamel finish walls should be lightly sanded, then washed with a common household detergent and allowed to dry completely. Any greasy surface should be cleaned with a strong ammonia solution and allowed to dry completely.

If the walls to be covered have highly contrasted colors or white patches on dark wall, prime over the contrasting areas until the entire area has a uniform color.

For drywall preparation countersink all nail heads. Tape or repair all joints or holes using joint tape or a wall patch and joint compound and let dry. Sand the wall to a smooth finish. Prime all new drywall with a wallpaper primer/sealer and follow primer instructions for the dry time.

Apply sizing to walls and let dry.

CARE & CLEANING

Once installed, your wallcovering may be cleaned using a soft sponge and a lukewarm, mild detergent solution. Do not use abrasive cleaners containing chlorine bleach, solvents, or ammonia as they may attack and damage the printed surface.

GETTING STARTED - PRE-PASTED MURALS

Extreme caution should be used when trimming or hanging wallcovering around electrical outlets. Turn off all electrical current to room at the fuse or circuit box.

This roll contains **all the panels** that comprise your mural, each **numbered sequentially** in the order that it will be installed, beginning on the left side of the mural. **Determine the location** that your mural is to be installed, and using a plumb bob or level, lightly **draw a line where the left edge** of the mural will fall. You will **align the left edge of your first panel** with this line.

If the left edge will be in a corner, draw the line **17.5" to the right of the corner**. You will **align the right edge** of the first panel with this line.

Depending on its dimensions, you may not want your mural to go all the way to the ceiling. If this is the case, use your level to lightly draw a line where you would like the top of the mural to fall. You will align the top of your first panel here.

HANGING PROCEDURE

Unroll and separate the panels. **Activate the paste on PANEL 1** by submerging the panel in a water tray filled with clean water (change water frequently to ensure it is clean). **Immediately draw the panel from the water tray** by lifting the outside end and letting the roll unwind as it is drawn out of the water. Be sure to slowly remove the panel so as to ensure paste is completely wet.

Gently place the moistened panel **directly on the wall and align it** with the vertical and horizontal guide lines you drew earlier. If your first panel is in a corner, it **will slightly overlap the corner**. This is to allow for variances in the corner and will be trimmed off later.

Smooth the panel in place with a slightly damp sponge, working any **air pockets toward the edges**. Do not use a brush or a metal or plastic blade as it may tear through the material or damage the printed surface. Use a damp sponge to **wipe excess paste from the panel** and surrounding wall area. Be sure to rinse the sponge frequently to maintain a clean surface.

Continue this method with the remaining panels. **Overlap the left edge of each new panel** with the right edge of the previous one. Before smoothing into place, **adjust the panels until the pattern is perfectly matched**.

The overlap at the **seam may be left as is or double-cut** for a smoother finish. To **double-cut** the seam, use a straight edge and sharp razor blade knife to **cut down the center of the overlap**. Peel away the thin strip that was trimmed off of the upper panel. Then slightly lift the edge of the upper panel to peel away the thin strip that was trimmed off of the lower panel. Press the upper panel back into place and smooth the seam. Use a damp sponge to clean the seams between each panel as you go. A small **roller will help press the edges in place** and ensure a good seam.

Once all the panels are in place, use a **sharp razor blade knife to trim any excess material**. Use a straight edge as a guide where needed, and wipe away any excess paste with a damp sponge.

shop4
wallpaper.com
4700 Lakeside Avenue
Third Floor
Cleveland, Ohio 44114

Need Help?
Visit:
www.shop4wallpaper.com
for installation videos, downloads, & more!
Or contact us at:
service@shop4wallpaper.com
1-800-496-4444

****CAUTION****
Plastic bag may be a
choking hazard.
KEEP AWAY FROM
SMALL CHILDREN

WARRANTY

Shop4wallpaper warrants its finished product to be free of defects in material and workmanship for a period of 90 days from purchase, and will replace any material found to be defective. Please inspect all goods immediately upon receipt. Shop4wallpaper is not responsible for labor charges, improper installation, installation of incorrect goods (those not approved or confirmed by the customer), removal of goods, or problems arising from defects in the construction, surface, or preparation of the wall.